

MK 5-EXTRA POWDER

A Blend of High Quality Polishing Materials

***For polishing Marble, Limestone, Travertine or Terrazzo Floors**

MK 5-EXTRA POWDER

TO APPLY MK 5-EXTRA POWDER YOU WILL NEED:

1. **MK 5-Extra Powder**
2. Floor Buffer (175-350 RPM) equipped with a water tank and splash guard.
3. One natural hair pad and white buffing pad.
4. Wet vacuum, mop, bucket wringer and floor squeegee.

DIRECTIONS:

Note: If the stone surface has wax or sealer to be removed or neutralized, use **MK Strip Klean** to effectively strip wax or sealer from the stone surface prior to use.

1. Cover baseboard, carpet etc...with protective plastic and/or tape.
2. Wet stone surface. Sprinkle **MK 5-Extra Powder** on the floor (5oz. / 25 sq. ft.) over an area no larger than 25 sq. ft. at a time.
3. The **MK 5-Extra Powder** water mixture should make a slurry. Buff this mixture with a natural hair pad for about 10 minutes per 25 sq. ft.
4. Check level of gloss with a squeegee. When the level of gloss is achieved, squeegee the **MK 5-Extra Powder** mixture to the adjacent area and repeat process.
5. Vacuum the **MK 5-Extra Powder** mixture. Wet the polished area again and buff with the same pad without adding more **MK 5-Extra Powder**.
6. Vacuum dry, damp mop with **MK Neutral Klean**, and let dry.
7. Buff polished area with a dry white pad.

COVERAGE: Up to 150 sq. ft. per lb.

DO NOT LET THE COMPOUND DRY IN THE GROUT JOINTS, AS IT MAY DISCOLOR THE JOINTS.

Marble Kare Products, Inc. will not be liable for any damage ensuing to property or injury to operator or other person due to the misuse or misapplication of **MK-Extra Powder** or any other chemical sold by them. **Store in a dry place.** For further technical specification, see Material Safety Data Sheet.