

# MK Natural Stone MPC™

MK Natural Stone MPC™ is a High Quality Blend of Polishing Materials

\*Easy to use

\*Polishes, hardens and protects Marble, Limestone, Travertine and Agglomerates

\*Enhances the color and beauty of natural stone

## MK Natural Stone MPC™

TO APPLY MK NATURAL STONE MPC™ YOU WILL NEED:

1. MK Natural Stone MPC™
2. Floor Buffer (175-350 RPM) equipped with a water tank and splash guard.
3. One natural hair pad and white buffing pad.
4. Wet vacuum, mop, bucket wringer and floor squeegee.

## DIRECTIONS:

Note if the stone surface has wax or sealer to be removed, use MK Strip Klean™ to effectively strip wax or sealer from stone surface prior to use.

1. Cover base board, carpet, etc. with protective plastic and/or tape.
2. Wet stone surface. Sprinkle MK Natural Stone MPC™ on the floor (5oz. / 25 sq.ft.) over an area no larger than 25 sq. ft. at a time.
3. MK Natural Stone MPC™ water mixture should make a slurry. Buff this mixture with a natural hair pad for about 10 min per 25 sq. ft.
4. Check the level of gloss with a squeegee. When the level of gloss is achieved, squeegee the MK Natural Stone MPC™ mixture to the adjacent area and repeat process.
5. Vacuum the MK Natural Stone MPC™ mixture. Wet the polished area again and buff with the same pad without adding more MK Natural Stone MPC™.
6. Vacuum dry, damp mop with MK Neutral Klean™, and let dry.
7. Buff polish area with a dry white pad.

**COVERAGE:** Up to 200 sq. ft. per lb.

**Marble Kare Products, Inc.** will not be liable for any damage ensuing to property or injury to operator or other person due to the misuse or misapplication of MK Natural Stone MPC™ or any other chemical sold by them. **Store in a dry place.** For further technical specification, see Material Safety Data Sheet.